

Iridium 9505A Basics



Turning the Phone On

2

Extent Antenna to upward position

1

Push down until display screen turn green.



3

Display screen will say "Enter Pin"

Pin # is 1111

4

Display screen may say "Searching", Then shows "Iridium" Phone is then ready to make calls

Placing A Call



To call a US phone number from the Satellite phone -

#1 Press 00

#2 Press 1

#3 Area Code and phone number

To call another satellite phone from your satellite phone –

#1 Press 00

#2 Press 881

#3 Press Phone Number (641499661)

Notes –

00 = international dialing prefix


881 = Iridium Country Code

Phone Number (satellite) = 9 numbers

UDOH – Preparedness Communications Projects

- **800 MHz Communications**
 - Hospital Common / DOH Main
 - 30 + Hospitals
 - LHD except Southeast Health and Tri-County Health
- **VHF Radio / Narrowbanding**
 - Rural Hospitals
- **VOIP/ROIP**
 - LHD Southwest Health, Central Valley Health, and Tri-County Health

Communication & Coordination



Questions?

Utah Department of Health
Bureau of EMS / Preparedness
24 Hr. Hotline Number
1-866-364-8824

Dan Camp
dcamp@utah.gov
801-450-6687 Cell